# American Wet Tank System Models: A3500 and A4500

Also Includes: A3525, A3535, A3575, A35100-ST A4525, A4535, A4575, A45100-ST

## A3575 - A4575

75 Gallon Units

Requires Three Bracket Assemblies
Use Kit Number:

AMK-624-C/3 (Carbon Steel)

AMK-624-S/3 (Stainless)

A35100-ST — A45100-ST

100 Gallon Units

Requires Four Bracket Assemblies
Use 2 of the following:

AMK-624-C (Carbon Steel)

AMK-624-S (Stainless)

## American Wet Tank System Models: A3500 and A4500

Mounting Kit Contents: Part Number AMK-624-C (carbon steel)

Part Number AMK-624-S (stainless steel)

### **Qty Description**

- 2 "J" brackets powder coted, radius is rubber lined (affixed)
- 2 2" wide strap assemblies including four Nyloc nuts

### Materials Required to Complete Installation:

### **Qty Description**

- 4 %" grade 5 bolts (length determined by installer)
- 4 Nyloc Nuts %" 11
- 8 %" washers

### Pre-packaged Kit Includes:

Steel or aluminum tank assembly (25 gallon through 100 gallon) with three, 1¼" NPT ports (75 gallon have 1½" NPT ports), (100 gallon have 2" NPT ports), the 50 gallon and larger units include auxiliary breather vent in tank for increased air exchange; each is provided with a filler breather assembly including 40 micron filter breather cap (chain mounted) with nylon strainer basket and bayonet closure; all ports in each unit are internally diffused (except 100 gallon); one port plug provided; all steel parts are powder-coated black; saddle mount bracket and strap assemblies are rubber shielded.

### Instructions:

- 1. Position the top of the cradle bracket flush with the truck frame rail.
- 2. Attach brackets to frame rail with at least (2) %", grade 5 bolts (per bracket).

Note: Brackets should be placed within 2" from ends of tank, 75 gallon tanks require and extra bracket (and strap) placed on either side of the fill cap, at least ½" from weld. 100 gallon tanks require two extra brackets (and straps), spaced evenly and at least ½" from weld.

- 3. Place tank against brackets and firmly tighten nuts to straps (not more than 25 ft.lbs. of torque).
- 4. Install plumbing. All plumbing and fitting connections attached to tanks must be properly supported into same moving plane as the tank in order to keep plumbing and fittings from creating a metal fatigue fracture outside of port weld. We suggest using a hose support mount (which we offer).

Note: Filter/breather cap should be periodically cleaned or replaced to prevent plugging and possible system damage.